



# Reloading Scales

Mechanical Balances



## *The Original OHAUS Reloading Scales are Back!*

The original OHAUS 5-0-5 and 5-0-2 Reloading Scales have been the standard in bullet-and-shot reloading for decades. Used by hunters, competitive sport shooters and archers since the 1960s, these scales are the standard for weighing charges to reload shells, checking ammunition and arrowheads, and designing custom loads. These balances offer the sensitivity of a beam balance, while incorporating our magnetic damping system to speed reloading.

### *Standard Features Include:*

- **Proven Design with 0.1 Grain Sensitivity**

Equipped with cast metal beams designed with wide-spaced deep notches to prevent accidental poise movement. Self-aligning agate bearings with steel beam pivots guarantee sensitivity to 0.1 grain.

- **Range of Features for Easy Operation**

Removable pan with handle and spout. Pan supports cradle the pan so that it doesn't tip off when weighing cases, loaded cartridges, arrows, etc. Ounce to grain conversion labels for quick reference.

- **Durable Mechanical Design to Last Years of Use**

Die-cast bases with large leveling feet for extra stability and durable stainless steel poises. Mechanical design allows for use on the bench or at the practice range—battery or AC power not needed.

- **A Full Family of Reloading Scales**

5-0-2 model with capacity to 505 grains is ideal for basic reloading, while the 5-0-5 offers capacity to 511 grains for more precise weighing.

# Reloading Scales Mechanical Balances

Model	5-0-2	5-0-5
Capacity	505 grains	511 grains
Readability	0.1 grain	0.1 grain
Dimensions L x W x H (in./cm)	11.9 x 3 x 3.9 / 30.2 x 7.62 x 9.9	
Poises	One painted metal One stainless steel	One painted metal Two stainless steel
Calibrations: First Poise Second Poise Third Poise"	1 grain 0.1 grain	5 grains 1 grain 0.1 grain
Tare Weight (included)	N/A	N/A
Net Weight	0.6 lb / 0.2 kg	
Shipping Dimensions L x W x H (in./cm)	10.75 x 3.5 x 4 / 27.3 x 8.9 x 7.6	
Shipping Weight	0.9 lb / 0.4 kg	

## Other Standard Features and Equipment

Die-cast base, durable cast metal beams and stainless steel fine poises, notched main beams with large markings for easy reading, hardened steel beam pivots, hanging pan supports, pans with handle and spout, single leveling foot on each scale, painted metal main poise, 500-grain tare weight and storage cover, mechanical design, magnetic damping system to speed reloading, self-aligning agate bearings, ounce-to-grain conversion label for quick reference, approach-to-weight feature, large zero indicator

80775117\_A 20190107 © Copyright OHAUS Corporation

### OHAUS CORPORATION

\* 7 Campus Drive  
Suite 310  
Parsippany, NJ 07054 USA

Tel: 800.672.7722  
973.377.9000  
Fax: 973.944.7177

[www.ohaus.com](http://www.ohaus.com)

*With offices throughout  
Europe, Asia, and  
Latin America*

\*ISO 9001:2008

Registered Quality  
Management System

